

Fluke Accessory Selection Guide

Find the right accessories to make your meter work for you

	7-300/7-600	10/11/12/12B	110/111/112	16	21/23/26/75/77/79	27	70/73 III	175/177	179	83/85/87 III/83V	87/89 IV	87V	187/189	45	867B	39/41B	43B	90 Series	120 Series	190 Series	50S/50D	51/52/53/54 II	61	65	63/66/68	321/322	333/334/335/336/337	705/707	712/713	714	715	716/717	718	725	741/743	744	787/789	T3/T5		
Current	i200				•	•	73		•	•	•	•	•	•	•																								3	
	i200s	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																		•	
	i400				•	•	73		•	•	•	•	•	•	•																								3	
	i400s	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	•	•	•	•																		3	
	80I-600A				•	•	73		•	•	•	•	•	•	•	•																							•	
	i1000s	4	4	4	4	4	4	4	4	4	4	4	4	4	4	4	•	•	•	•																				
	i2000flex	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	i3000s	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	i410	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	5	5	5	5																			
	i1010	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	5	5	5	5																			
Temperature	80AK			•					•	•	•	•	•	•	•																									
	80BK			•					•	•	•	•	•	•	•																									
	All 80PK probes	1	1	2	1	1	1	1	2	1	2	2	2	1	1							•	•																1	
	80PJ-1 & 80PJ-9																					•	•																	
	80PT-25																					•	•																	
	80TK	•	•		•	•	•	•		•	•	•	•	•	•	•	•	•	•	•																				
	80T-150U	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	80PJ-EXT																					•	•																	
	80PK-EXT	1	1	2	1	1	1	1	2	1	2	2	2	1	1							•	•																	
	80PT-EXT																					•	•																	
	80CK-M	1	1	2	1	1	1	1	2	1	2	2	2	1	1							•	•																	
	80CJM																					•	•																	
80PR-60																					•	•																		
Cases and Holsters	C510	•	•	•	•																•	•																	787	
	C520																																							
	C550	Large enough to hold accessories and multiple test tools																																						
	C12A	•	•	•	•																																			
	C23	•	•	•	•																																			
	C25				•	•	•	•	•	•	•	•	•	•	•	•						•	•																	
	C33																																							
	C43																																							
	C50	•	•	•	•																																			
	C90			•	•	•																																		
	C125			•	•	•																																		
	C789																																							
	C20																																							
	C101	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	C10	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	C70Y																																							
	H80M																																							
	H3																																							
	H5																																							
	H6																																							
Test Leads	ToolPak Meter Hanger		•																																					
	LockPak Meter Lock																																							
	Standard Test Lead Input	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U	U																				
	TL220	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	TL223	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	TL225	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	TL238	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	TL80A																																							
	TL81A																																							
	TL71	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
TL76	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																				
Specialty	FlukeView® Forms Software																																							
	PV350 (pressure)	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	FOM (fiber optic)	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
	CO-210	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																			
80K-6, 80K-15, 80K-40	dc	dc	dc	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•																				

(1) Requires 80TK (2) Requires 80AK (3) Limited low level ac capability - see page 37 (4) Requires PM9081/001 Adapter (5) Requires PM9082/001 adapter
 U A universal accessory. Works with most brands of meters.
 For detailed Current Clamp specifications see pages 40 and 41.
 *Included with the 12B and 16 ** 53, 54 only